



Ross GK30

QAC based terminal disinfectant for open plant applications

Ross GK30 is a broad-spectrum terminal disinfectant for excellent disinfectant activity against most vegetative forms of micro-organisms including Gram positive and Gram-negative bacteria, yeasts & molds.

Product is applied after thorough cleaning of surface for disinfection. It can be used to disinfect floors, walls, utensils and on other food product preparation equipment and is suitable for use in meat and poultry processors, snack foods, dairies and most type of foods processing operations.

Key Benefits

- Suitable with hard water too
- Broad spectrum terminal disinfectant
- Non-corrosive
- Non-tainting

Application Method

Product can be used manually, by soak or by spray application in the concentration of 1-5% depending upon the application. Rinse of the surface thoroughly with water after use.

For more details, please contact your local Buzil Rossari representative.

Technical Data

Appearance	Clear colorless liquid
pH (10% solution)	7.5 ±1
Odour	Characteristics
Solubility	Soluble in water
Pack Size	30 Kg



Ross GK30

QAC based terminal disinfectant for open plant applications

Microbiological Data

EN 1276: passed at 0.5% dilution in hard water (300ppm as CaCO_3), low soil (0.03% bovine albumin) and 5 minutes contact time.

Safety Assessment

Eye contact: Flush with water for at least 15 minutes. If irritation occurs and persists, obtain medical attention.

Skin contact: Wash with plenty of soap and water. If irritation occurs and persists, obtain medical attention. Wash clothing before reuse.

Inhalation: Get fresh air. If difficulty in breathing or discomfort occurs, call a physician.

Ingestion: Drink one to two glasses of water. Do not induce vomiting. Do not give anything by mouth to an unconscious individual. Call a physician immediately.

Storage and Handling

All safety information on the handling and use of this product is provided in the Safety Data Sheet which can be consulted and / or obtained from our representatives

Keep this product in the original packaging or, where possible, in a tank of bulk reception, protected from extreme temperatures.

Declaration: Technical figures given in this data sheet are typical values based on internal laboratory measurements, following appropriate International Standard Methods, and should not be taken as a warranty or representation. It is the end user's responsibility to make sure that the product matches its requirements.

For more information on this product, please contact your local Buzil Rossari representative.

Buzil Rossari Private Limited

402, OMEGA, Hiranandani Business Park, Powai, Mumbai – 400 076, Maharashtra, INDIA.

Tel.: +91-22-25701619 / 67411126, Mail: marketing@buzil-rossari.com, Web: www.buzil-rossari.com



Ross GK30

QAC based terminal disinfectant for open plant applications

Food Grade Quality Certificate

Application in food & beverage processing facilities

Here we confirm that, **Ross GK30**, if used according to the instructions mentioned in the product information sheet or intended use, is suitable for use in Beverage, Brewing, Dairy & Food Processing facilities and not to adulterate the food product in any manner during its use.

Essential condition is a thorough rinsing with clear portable water of surfaces intended to get in direct contact with foodstuff.

The remaining residuals that may contaminate or adulterate food contacting cleaned surfaces are expected to be negligible, following a potable water rinse. Therefore, the potential ingestion of residues resulting from the approved use of these types of products does not represent a significant health hazard after our assessment of the products as suitable for use under the intended conditions.



Thanking you,

Yours faithfully,

For Rossari Biotech Ltd.

Please note that this is not a regulatory assessment and should not be construed as an endorsement of regulatory compliance.

MATERIAL SAFETY DATA SHEET

according to REGULATION (EU) No 453/2010, annex I

Ross GK30

Date of issue: 11.11.2018

Page 1 of 6

1. Identification of the mixture and of the company / undertaking

1.1. Product identifier

Ross GK30

1.2. Relevant identified uses of the mixture and uses advised against

Professional cleaning/maintenance product for food & beverage industries.

1.3. Details of the supplier of the safety data sheet

Manufacturer:

Manufactured under licence from buzil
ROSSARI BIOTECH LIMITED
Plot No. 10 & 11, Survey No.90/1/10 & 90/1/11/1,
Kumbharwadi, Village Naroli
Silvassa-396235
Dadra and Nagar Haveli (UT)
India

e-mail info@rossarimail.com

www.buzil-rossari.com & www.rossari.com

1.4. Emergency telephone number

+91-22-61233800/61233887

MATERIAL SAFETY DATA SHEET

according to REGULATION (EU) No 453/2010, annex I

Ross GK30

Date of issue: 11.11.2018

Page 2 of 6

2. Hazards identification



Risk phrases :

Hazards for man and the environment :

R 22 Harmful if swallowed

R 34 Causes burns

Classification system : The classification complies with current EC regulations on dangerous substances and preparations.

3. Composition / information on ingredients

Chemical characterization

Description : Mixture in water of non-dangerous ingredients and substances listed below.

Hazardous ingredients :

CAS: 61789-71-7 Benzalkonium Chloride R 22, R34 5-15%

Additional information : The full text of the relevant risk phrases is given in section 16.

4. First aid measures

General information : Remove contaminated clothing immediately.

Inhalation : Remove from source of exposure. Obtain medical attention if symptoms develop.

Skin contact : No special measures required.

Eye contact : Wash skin immediately and thoroughly with water. Remove contaminated clothing.

Obtain medical attention if symptoms develop.

Ingestion : Rinse out mouth and then drink one or two glasses of water(or milk). Obtain medical attention.

MATERIAL SAFETY DATA SHEET

according to REGULATION (EU) No 453/2010, annex I

Ross GK30

Date of issue: 11.11.2018

Page 3 of 6

5. Firefighting measures

Suitable extinguishing media : CO2, extinguishing powder or water jet. Fight larger fires with water jet or alcohol resistant foam.

Protective equipment : No special measures required

6. Accidental release measures

6.1. Personal precautions, protective equipment and emergency procedures

Not required

6.2. Environmental precautions:

Dilute with plenty of water

6.3. Methods and materials for containment and cleaning up

Absorb with liquid-binding material (sand, diatomite, universal binders, sawdust). Dispose of the collected material according to the regulations.

6.4. Reference to other sections

Follow advices and protective measures mentioned in section 7 and 8.

7. Handling and storage

Handling (see also sections 8 and 15)

Information for safe handling : Use common rules for working with chemicals.

Information about protection against explosions and fires : No special measures required.

Storage :

Requirements for storage rooms and containers : According to local legislation.

Storage in one common storage facility : According to local legislation.

Further information about storage conditions : None.

MATERIAL SAFETY DATA SHEET

according to REGULATION (EU) No 453/2010, annex I

Ross GK30

Date of issue: 11.11.2018

Page 4 of 6

8. Exposure controls / personal protection

Additional information about design of technical systems : No further data; see section 7.

Components with limit values that require monitoring at the workplace :

Additional information : The lists that were valid during the compilation were used as basis.

Personal Protection equipment :

General protective and hygienic measures :

Keep away from foodstuffs, beverages and food. Take off immediately all contaminated clothing.

Wash hands during breaks and at the end of work. Do not inhale gases /fumes /aerosols.

Avoid contact with the eyes and skin.

Breathing equipment : Personal protection is not normally required. However, inhalation of dust, vapour or aerosols should be avoided.

Protection of hands : Use safety gloves.

Eye protection: Safety glasses recommended during handling the undiluted product that involves a risk of splashing.

9. Physical and chemical properties

Information on basic physical and chemical properties

Appearance: Clear liquid

Odour: Characteristic

pH-value(10%): 7.5 ± 1

Melting point / melting range: ND

Boiling point / boiling range: ND

Density (25 °C): 0.99 - 1.05 gm/cm³

Solubility in / miscibility with water: Miscible in water

Viscosity (25 °C): ND

Specific gravity: ND

MATERIAL SAFETY DATA SHEET

according to REGULATION (EU) No 453/2010, annex I

Ross GK30

Date of issue: 11.11.2018

Page 5 of 6

10. Stability and reactivity

Thermal decomposition / conditions to be avoided : No decomposition if used according to specifications.

Dangerous reactions : None.

Hazardous decomposition products : None.

11. Toxicological information

Information on toxicological effects

Acute toxicity:

Primary irritant effect:

Skin contact : Unlikely to be irritant in normal use

Eye contact : Causes severe irritation.

Inhalation : Causes irritation.

Ingestion : Causes irritation.

12. Ecological information

General notes : Must not reach sewage water or drainage ditch undiluted or unneutralized. When used for its intended purpose this product should not cause adverse effects in the environment.

The information in this section refers to the undiluted product.

13. Disposal considerations

Product Recommendation : Must not be disposed of with domestic waste. Do not allow undiluted product to reach sewage system.

Uncleaned Packagings Recommendation : Dispose of observing official regulations.

Recommended cleaning agent : Water, if necessary with cleaning agent.

MATERIAL SAFETY DATA SHEET

according to REGULATION (EU) No 453/2010, annex I

Ross GK30

Date of issue: 11.11.2018

Page 6 of 6

14. Transport information

Land transport ADR/RID (cross-border)

ADR/RID Class :

Maritime transport IMDG :

IMDG Class:

Air transport ICAO-TI and IATA-DGR :

ICAO / IATA Class :

Transport / Additional Information : Non dangerous according to above regulations

15. Regulatory information

Classification according to EC guidelines : The product has been classified and labeled in accordance with current EC Directives.

Symbol and hazard designation of product:



16. Other information

The information in this document is based on our best present knowledge. However, it does not constitute a guarantee or any specific product features and does not establish a legally binding contract.



Analytical Test Methods

Product	Ross GK30	Issued On	01/01/2018
Application	Disinfection	Next Review On	01/01/2023

Method of Activity

Reagents, Apparatus & Instruments

0.004M SLS Solution, *Methylene blue indicator solution, Chloroform

*Dissolve 0.5g of methylene blue in 100l DM water, Pipette 6ml of this solution into a 1ltr. standard volumetric flask. Add some DM water. Dissolve 50mg of Sodium Sulphate, GR/LR quality. In some DM water mix 6.7ml of Sulphuric acid.

Add this solution in the volumetric flask to make the volume of 1ltr using DM water.

Conical & Volumetric Flask, Burette, Weighing Scale

Method

Solution A : Mix 100ml of DM water with 2-3gms of Ross GK30 and pour the solution in burette.

Solution B: In a separate flask take solutions of mix 25ml of Methylene blue indicator solution, 15ml Chloroform and add 10ml of SLS solution.

Titrate B solution against solution A, until the tinge of blue colour in both phases match.

Take a note of burette reading as BR and calculate the activity as follows,

Calculation

Activity % = $1414 / (\text{Weight of sample} \times \text{BR})$

Activity % will be 95% or above

User concentration

Reagents, Apparatus & Instruments

0.004M SLS Solution, *Methylene blue indicator solution, Chloroform

*Dissolve 0.5g of methylene blue in 100l DM water. To 0.6ml of this solution add 50g of anhydrous sodium sulphate (dissolved in DM water), 120ml of 12N Sulphuric Acid and dilute to 1 litre with distilled water

Stopped Cylinder, Burette, Pipette

Method

- Pipette out of 5ml of 0.004M SLS Solution in a 100ml stopped cylinder
- Add 25ml of Methylene blue indicator solution, 15ml of Chloroform and shake. Allow to stand, two layer will be visible. The upper layer will be light blue and lower layer will be of Chloroform in dark blue.
- Take the test solution and dilute Ross GK30 sample in burette and titrate with above solution in stopped cylinder.
- Run 0.5-1.0ml at a time and shake 10 times. Keep the cylinder for standing till the emulsion separates.
- Continue the titration dropwise, shaking thoroughly after each addition and judge the color intensity of both layers in the viewing cabinet or white background.
- End point is obtained when the blue color intensity of both layers matches or is same. Record the volume of titrant used at the end point as "A" ml.
- If the blue color intensity of the top layer is more than the end point is crossed or excess titrant is added.

Calculation

Concentration in PPM : $(7.0 \times 10^3) / \text{"A" ml}$